

## NOTES:

- 1. All added wires are Arctic Ultraflex 14 AWG, Polar Wire P/N AUF-14-COLOR
- Use #8 flat-head wood screws, Phillips drive.
  Screws must NOT protrude from underside of wood.



303-381-7451 fax	Dr., Boulder CO 80301 Date Modified: June 11 2009	CES		lnc [	oard	Station
SHEET 2	Date Modified:	Approval:	Engineering: S. White	Drawing:	PPS-D	Part Number
оғ <b>3</b>	June 11		S. White	S. White	C-006	mber
	2009				PPS-DC-006 TEMP	Rev