



REV	Description	Date	Appr.
A	Initial Release	5/23/08	
B	TNC and vent switched places, thru holes for RF bulkheads.	4/20/09	BJ
C	Add GPS + commis surge protectors, connector layout changed	5/16/13	



- NOTES:
1. See Sheet 2 for drilling details (internal view)
  2. All connectors mounted from the outside of enclosure.
  3. Power bulkhead pass-thru connectors are mounted with pins facing outward, and key oriented upward
  4. Use PEI Genesis nut plates and 4-40 x 1/2" socket-head cap screws to attach power bulkhead pass-thru connectors
  5. Ground plate: UNAVCO P/N PPS-EN-012
  6. Connector drilling template: UNAVCO P/N PPS-EN-004

		<b>Polar Permanent GPS Station</b> <b>MM36 Enclosure Connector Layout</b>	
UNAVCO, Inc. POLAR SERVICES 6350 Nautilus Dr., Boulder CO 80301 303-381-7500, 303-381-7451 fax		<b>Part Number</b> <b>PPS-EN-010</b>	<b>Rev</b> <b>C</b>
Drawing: <b>S. White</b> Engineering: <b>S. White</b> Approval:		Date Modified: <b>May 16 2013</b> SHEET <b>1</b> OF <b>2</b>	